



## INSTALLATION INSTRUCTIONS OF HAND CRANK HEIGHT ADJUSTABLE DESK





## Screws pack


























## Waste Disposal





This sign indicates that the product should not be treated together with other domestic waste. In order to prevent potential harm to the environment and human beings caused by random treatment, It should be recycled to promote the sustainable reuse of material resources. When returning the equipment you use, please use the recycling and collection system or contact the retailer who purchased it. They are able to recycle while ensuring environmental safely.